



Better
shape
capture.
Better fit.

**Majicast helps you begin
fitting from shape capture
under weight-bearing
conditions.**



Hydrostatic, weight-bearing
fitting



Better distal shape



Telescopic top tank



Portable & mobile use



Consistent outcomes



Remoldable
& fast fitting

Weight-bearing shape capture made simple and repeatable



1 Prepare the residual limb



2 Position and secure the socket



3 Capture shape under load



4 Finalize and refine the fit



See how Majicast improves the starting point for fit.

Book a demo to explore hydrostatic weight-bearing shape capture, direct fitting, and repeatable workflow options with the Amparo System.